




EASY PROGRAMMING

1 Smart controller panel & keys



Main Window

Brightness: Evenly change according to the time you setting of the sunrise and sunset.
Start at: The time of sunrise end
End at: The time of sunset start


2 Remote controller



3

Menu Operation

1.Display Window:




Brightness: Evenly change according to the time you setting of the sunrise and sunset.
Start at: The time of sunrise end
End at: The time of sunset start

Note: Mode can be change by ◀▶ button.


2.Mode Configuration

Timer mode setting

Step1: Press "menu" to enter the function setting.



Step2: Press "ok" button to enter timer mode.




Step3: Press ◀▶ to choose sunrise or sunset and press ▲▼ to change the time you prefer.

Step4: Press "menu" back to the functions

Dimmer mode setting

Step1 : Press "ok" button to enter dimmer mode.





Step2: Press ◀ ▶ to choose sunny or moon and press ▲ ▼ to change the brightness percent you prefer.


Step3: Press "menu" will back to the functions

Temp. mode setting


Step1: Press "ok" button to enter temp. mode.



Step2: Press ▶ to choose dimming temp.




Step3: Press ► to choose auto off.




press ▲ ▼ to turn on or off the auto off

Step4: Press ► to choose off temp.



press ▲ ▼ to change the off temp.

Step5: Press ► to choose Temp. unit.




press ▲ ▼ to change the temp unit you want


Step6: Press menu will back to the functions.


System mode setting

Press ok button to enter system mode.




press 'ok' key






press '▲' '▼' to change the date.

Step2: Press ► to choose the Clock.




press '▲' '▼' to change the clock.

Step3: Press ► to choose the Lcd contrast.



press '▲' '▼' to change the lcd contrast.

Step4: Press ► to choose the Factory default.



press '▲' '▼' to choose yes or no.

Last step: press menu once back to Functions , press menu again will back to interface.